# DOSIMETER DESIGN PROGRAM

Craig J. Kief

COSMIAC at UNM 2350 Alamo Avenue SE, Ste 300 Albuquerque, NM 87106

5 Jan 2015

**Final Report** 

APPROVED FOR PUBLIC RELEASE; DISTRIBUTION IS UNLIMITED.



AIR FORCE RESEARCH LABORATORY Space Vehicles Directorate 3550 Aberdeen Ave SE AIR FORCE MATERIEL COMMAND KIRTLAND AIR FORCE BASE, NM 87117-5776

# DTIC COPY NOTICE AND SIGNATURE PAGE

Using Government drawings, specifications, or other data included in this document for any purpose other than Government procurement does not in any way obligate the U.S. Government. The fact that the Government formulated or supplied the drawings, specifications, or other data does not license the holder or any other person or corporation; or convey any rights or permission to manufacture, use, or sell any patented invention that may relate to them.

This report is the result of contracted fundamental research deemed exempt from public affairs security and policy review in accordance with SAF/AQR memorandum dated 10 Dec 08 and AFRL/CA policy clarification memorandum dated 16 Jan 09. This report is available to the general public, including foreign nationals. Copies may be obtained from the Defense Technical Information Center (DTIC) (http://www.dtic.mil).

AFRL-RV-PS-TR-2014-0168 HAS BEEN REVIEWED AND IS APPROVED FOR PUBLICATION IN ACCORDANCE WITH ASSIGNED DISTRIBUTION STATEMENT.

//SIGNED// KEITH AVERY Program Manager //SIGNED// JAMES LYKE Tech Advisor, Space Electronics Protection Branch

//SIGNED//

BENJAMIN M. COOK, Lt Col, USAF Deputy Chief, Spacecraft Technology Division Space Vehicles Directorate

This report is published in the interest of scientific and technical information exchange, and its publication does not constitute the Government's approval or disapproval of its ideas or findings.

## **REPORT DOCUMENTATION PAGE**

Form Approved OMB No. 0704-0188

Public reporting burden for this collection of information is estimated to average 1 hour per response, including the time for reviewing instructions, searching existing data sources, gathering and maintaining the data needed, and completing and reviewing this collection of information. Send comments regarding this burden estimate or any other aspect of this collection of information, including suggestions for reducing this burden to Department of Defense, Washington Headquarters Services, Directorate for Information Operations and Reports (0704-0188), 1215 Jefferson Davis Highway, Suite 1204, Arlington, VA 22202-4302. Respondents should be aware that notwithstanding any other provision of law, no person shall be subject to any penalty for failing to comply with a collection of information if it does not display a currently valid OMB control number. PLEASE DO NOT RETURN YOUR FORM TO THE ABOVE ADDRESS.

1. REPORT DATE (DD-MM-YY)	2. REPORT TYPE	3. DATES COVERED (From - To)
05-01-2015	Final Report	16 Jul 2013 to 16 Oct 2014
4. TITLE AND SUBTITLE		5a. CONTRACT NUMBER
Dosimeter Design Program		
		FA9453-13-1-0283
		5b. GRANT NUMBER
		OD. CICART NOMBER
		5c. PROGRAM ELEMENT NUMBER
		63401F
6. AUTHOR(S)		5d. PROJECT NUMBER
		2181
Craig J. Kief		5e. TASK NUMBER
		PPM00017001
		5f. WORK UNIT NUMBER
		EF011499
7. PERFORMING ORGANIZATION NAME(S) AND ADDRESS(ES)		8. PERFORMING ORGANIZATION REPORT
		NUMBER
COSMIAC at UNM		
2350 Alamo Avenue SE, Ste 300		
Albuquerque, NM 87106		
9. SPONSORING / MONITORING AGEI	NCY NAME(S) AND ADDRESS(ES)	10. SPONSOR/MONITOR'S ACRONYM(S)
Air Force Research Laboratory		AFRL/RVSE
Space Vehicles Directorate		
3550 Aberdeen Ave., SE		11. SPONSOR/MONITOR'S REPORT
Kirtland AFB, NM 87117-5776		NUMBER(S)
111111111111111111111111111111111111111		AFRL-RV-PS-TR-2014-0168
12. DISTRIBUTION / AVAILABILITY ST	ATEMENT	AFRE-R V-1 5-1 R-2014-0100
12. DIGINIDO HON/AVAILADILH   31	AT LINE IN T	

Approved for Public Release; Distribution is Unlimited.

#### 13. SUPPLEMENTARY NOTES


### 14. ABSTRACT

The purpose of this research project was to explore the various aspects of dosimeter development with a particular focus on nanosatellites. The team at the University of New Mexico's COSMIAC Center created a series of two different dosimeters for space flight. The first dosimeter was for low earth orbit and as such, didn't require radiation hardened electronics. The second dosimeter was created to fly in a much higher environment so it was designed to operate with radiation hardened electronics. The developed dosimeter system is called the Radiation Hazard Assessment System (RHAS). The RHAS was developed to monitor the radiation environment in a geosynchronous satellite.

#### 15. SUBJECT TERMS

Radiation testing, Cobalt, Microcontroller

16. SECURITY CLASSIFICATION OF:		17. LIMITATION	18. NUMBER	19a. NAME OF RESPONSIBLE PERSON	
		OF ABSTRACT	OF PAGES	Keith Avery	
a. REPORT Unclassified	b. ABSTRACT Unclassified	c. THIS PAGE Unclassified	Unlimited	78	19b. TELEPHONE NUMBER (include area code)



### **ACKNOWLEDGEMENT**

This material is based on research sponsored by Air Force Research Laboratory or the U.S. Government under agreement number FA9453-13-1-0283. The U.S. Government is authorized to reproduce and distribute reprints for Governmental purposes notwithstanding any copyright notation thereon."

### **DISCLAIMER**

The views and conclusions contained herein are those of the authors and should not be interpreted as necessarily representing the official policies or endorsements, either expressed or implied, of Air Force Research Laboratory or the U.S. Government.

# **Table of Contents**

1.	Summary	′
2.	Introduction	1
3.	Methods, Assumptions, and Procedures	2
4.	Results and Discussion	4
5.	Conclusions	5
Арр	endix: Source Files for RHAS	(
List	of Abbreviations, Symbols, and Acronyms	7′

### 1. Summary

The University of New Mexico (UNM) proposed to develop a series of dosimeter flight articles for use in future small satellite missions. The Configurable Space Microsystems Innovations and Applications Center (COSMIAC) aerospace and defense center at UNM worked on two CubeSats for delivery to the National Aeronautics and Space Administration (NASA) in 2013 and 2014. Dosimeters provide a critical way to measure the radiation at various altitudes and orbital inclinations. By understanding the actual levels, this allows developers of large (and very expensive) satellites to be able to use less expensive parts that meet minimum requirements for survivability.

### 2. Introduction

The current trend in nanosatellites is the use of a standard called the CubeSat. The CubeSat form factor is described with the use of "U" for units. A 1U is 10cm x 10cm x 10cm. A 6U is 10cm x 20cm x 30cm. UNM completed the design build and launch of a 1U CubeSat called Trailblazer (see Figure 1) that was launched in November of 2013 upon the ORS-3 mission. In addition, COSMIAC is working to complete a 6U spacecraft called ORS Squared for launch in late 2014. This spacecraft is shown in Figure 2.



Figure 1. Trailblazer

The team said that they would use the provided funds to complete three major goals:

 Design of a dosimeter that is not radiation hardened. The team will work to create a dosimeter design using parts that are not radiation hardened. This will allow for a dosimeter that can be used on any inexpensive CubeSat designed for

Low Earth Orbit (LEO). Satellites flown in LEO are often provided with natural protection from harmful effects normally found in the outer environment. The Earth's natural barriers provide protection for the planets occupants as well as spacecraft that stay close to the Earth's surface (200km – 400km) from many of the effects of solar radiation. This means that standard commercial electronics (which are much cheaper) can often be utilized. Non-hardened parts can often be an order of magnitude less in cost.




Figure 2. ORS

- Design a dosimeter that is radiation hardened. We will use the funding to create initial designs for a dosimeter that is built on radiation hardened parts designed for much higher orbits. There will be no prototype developed under this activity since the cost for the radiation hardened parts would be prohibitive. Various chips that are radiation hardened will be purchased for analysis.
- Develop Space Plug-and-play Architecture (SPA) interfaces for the dosimeters.
  The Air Force Research Laboratory has created a bus architecture call the SPA.
  This design paradigm allows for easy integration of modules into a spacecraft or
  other system. The team will work to develop a pathway ahead to make sure that
  both versions of the dosimeter could have a SPA interface.

# 3. Methods, Assumptions, and Procedures

Goal 1: The team created a simple non hardened dosimeter that was completed in time to be flown on the Trailblazer satellite in November of 2013. Unfortunately, this satellite was never heard from once on orbit so minimum results from on orbit are available. However, this design was also evaluated for flight in future COSMIAC satellites. An example schematic for the board is shown in Figure 3 (full schematics are provided upon request). We believe there is significant value to this design in its simplicity. We began work with other schools within the AFRL University Nanosat Program (UNP) to see if this is a sensor that they would like to fly on their spacecraft. Its design (with its low power and inexpensive parts) makes it an excellent sensor platform for a UNP satellite. We can provide any UNP partner with the complete schematics, bill of materials and board design files.




Figure 3. Board schematic subset

Goal 2: The radiation hardened version of this dosimeter board has been designed. Although there was no initial intent to actually create the hardware platform, resources and unforeseen opportunities provided the ability for the team to actually create this type of platform. We created the board as shown in Figure 4. COSMIAC has coordinated to find a flight opportunity for this dosimeter board on a Massachusetts Institute of Technology (MIT)/Lincoln Lab satellite for 2015. Engineering models were created and provided to integration teams at MIT. All problems that have been identified so far have been resolved. The schematics for the board are very similar to the ones shown in Figure 3 for the non-hardened version. The main difference is the use of parts that can withstand the rigors of deep space. With the assistance of AFRL's Space Weather Center of Excellence, we were able to do flight environmental testing and qualification. Electromagnetic interference testing identified potential areas of concern that were addressed by the inclusion of increased metal sheeting. AFRL Space Vehicles personnel assisted with total dose radiation testing on Kirtland Air Force Base. The developed dosimeter system was called the Radiation Hazard Assessment System (RHAS). The RHAS was originally developed to monitor the radiation environment in a geosynchronous satellite. It incorporates three Teledyne uDos001 dosimeters to measure total ionizing dose resulting from either proton or electron strikes in the space environment. The dosimeters employ a silicon detector which responds to energy deposits in the range of 100 kilo-electron volt to 15 Mega-electron volt. The current pulses from the detector are integrated, and when the resulting charge quanta reach a threshold equivalent to 14 micro-radians, a counter is incremented. counter output is applied to a digital to analog converter which drives the three output ranges (low, medium, and high) that are progressively scaled by 256 (i.e., medium range = 256\*low range, etc.).

The RHAS instrument shown in Figure 4 was designed to fit in a CubeSat format. The three dosimeters are located on the top side of the instrument board. In their current application, a different effective thickness of shielding (not shown here) is applied over each dosimeter to provide an indication of the energy spectrum of the space radiation. The instrument incorporates radiation hardened electronics including: an Aeroflex 8051 microcontroller, a Maxwell Electrically Erasable Programmable Read-Only Memory (EEPROM), Texas Instrument analog to digital converters, and associated support electronics. Appendix A contains the source code used for this instrument. The electronics are specified to a hardness level of 1 Mega-radian/Silicon total dose and are latch-up free. COSMIAC can provide additional radiation testing to higher total dose levels if required.




Figure 4. Flight model of RadHard Dosimeter

Goal 3: The tricky part of SPA is that the versions changed in the middle of the project. The original version that existed when this proposal was written was called the Satellite Data Module (SDM). The new version is called the Satellite System Module (SSM). SSM is much more mature and of higher quality. Also, this software has now been released as open source by AFRL. This greatly increases the ability to utilize it for student projects. The non-hardened version of the dosimeter board is already SPA compatible (older SDM version). The development of the SPA version of the hardened board was evaluated and then decided against. Future plans for SPA within the larger satellite community are very much in a state of flux so it was deemed that doing this development (at this time) would provide very limited benefit. Evaluation was made on what needed to be accomplished should this be desired later. Hardware and software stubs have been put into place to allow for easy integration at a later time.

### 4. Results and Discussion

The results to date are that the first iterations of the boards have been created. Ongoing testing has begun but will need to be continued for months to completely confirm that the systems are operating within acceptable parameters. Since a launch opportunity has been found, the next iterations will involve the creation of a control system to be able to interface the dosimeter into a larger orbital platform.

# 5. Conclusions

The conclusions are that it is possible for an academic institution to be able to create a radiation detection system on a limited budget that has space community level utility to achieve the required work for measurements in a space environment.

# **Appendix: Source Files for RHAS**

### **File List**

Here is a list of all files with brief descriptions:

ADC.c	7
Dosimeter.c	19
Interface.c	
MAIN.C	37
Packet.c	
Scheduler.c	64
SIO.C	

### **File Documentation**

#### **ADC.c** File Reference

#include "main.h"

#### **Functions**

- tByte read\_dosimeter\_all (tByte mode2)
- tByte read\_dosimeter\_low ()
- tByte check\_rollover (tByte val, tByte old\_val)
- tWord **compute\_avg** (tWord x, tWord xmean)

### **Variables**

- tByte tick = 0
- tByte **mode**
- tByte **count** = 0
- tWord curr val
- tByte **k** [] = {0, 0, 0, 0, 0}
- tLong idata dos [3]
   INSTRUMENT CONTROL Dosimeter Telemetry Application (Main module) (Version 2.0: Flight Software)
- tLong idata dos\_zero [3]
- tLong idata cal\_pre [3]
- tLong idata cal\_post [3]
- tLong idata TickCount
- Status1 type idata Status1
- tByte code adc\_ch [20]
- tByte code adc\_ch\_mode2 [3][5]
- tWord idata ps\_15V
- tWord idata **ps 5V**
- tWord idata temps [3]
- bit RunOnce
- bit ReadAllIsRunning

### **Function Documentation**

tByte check\_rollover (tByte val, tByte old\_val)

Definition at line 325 of file ADC.c.

tWord compute\_avg (tWord x, tWord xmean)

Definition at line 338 of file ADC.c.

tByte read\_dosimeter\_all (tByte mode2)

Definition at line 45 of file ADC.c.

tByte read\_dosimeter\_low ()

Definition at line 227 of file ADC.c.

**Variable Documentation** 

tByte code adc\_ch[20]

Definition at line 104 of file MAIN.C.

tByte code adc\_ch\_mode2[3][5]

Definition at line 91 of file MAIN.C.

tLong idata cal\_post[3]

Definition at line 36 of file MAIN.C.

tLong idata cal\_pre[3]

Definition at line 35 of file MAIN.C.

tByte count = 0

Definition at line 8 of file ADC.c.

tWord curr\_val

Definition at line 9 of file ADC.c.

tLong idata dos[3]

INSTRUMENT CONTROL Dosimeter Telemetry Application (Main module) (Version 2.0: Flight Software)

This code implements the full INSTRUMENT CONTROL dosimeter sensor, including all message formatting, data processing, and utility functions (ADC, CRC, ...)

Version Rev. 1.0 Created from the code written by Brian Zufelt for the development board and by code written by me for the EU model.

Chip type: Aeroflex UTMC UT69RH051 Program type: Firmware Core Clock

frequency: 16.129000 MHz

Definition at line 33 of file MAIN.C.

tLong idata dos\_zero[3]

Definition at line 34 of file MAIN.C.

 $tByte \ k[] = \{0, 0, 0, 0, 0, 0\}$ 

Definition at line 10 of file ADC.c.

tByte mode

Definition at line 7 of file ADC.c.

tWord idata ps\_15V

Definition at line 38 of file MAIN.C.

tWord idata ps\_5V

Definition at line 39 of file MAIN.C.

bit ReadAllIsRunning

Definition at line 81 of file MAIN.C.

bit RunOnce

Definition at line 84 of file MAIN.C.

Status1\_type idata Status1

Definition at line 78 of file MAIN.C.

tWord idata temps[3]

Definition at line 40 of file MAIN.C.

# $tByte\ tick = 0$

Definition at line 6 of file ADC.c.

tLong idata TickCount

Definition at line 57 of file MAIN.C.

```
// ADC.c
// This code implements all variants of the ADC functions
#include "main.h"
tByte\ tick = 0;
tByte mode;
tByte count = 0;
tWord curr val;
tByte k[] = \{0, 0, 0, 0, 0, 0\};
extern tLong idata dos[3];
extern tLong idata dos zero[3];
extern tLong idata cal pre[3];
extern tLong idata cal post[3];
extern tLong idata TickCount;
extern Status1 type idata Status1;
extern tByte code adc ch[20];
extern tByte code adc ch mode2[3][5];
extern tWord idata ps 15V;
extern tWord idata ps 5V;
extern tWord idata temps[3];
extern bit RunOnce:
extern bit ReadAllIsRunning;
* read dosimeter all()
* Reads the actual values of the high, medium, and low channels
* of a dosimeter and stores the results in a 32-bit value (in the
* form: High:12, Med:12, Low:8
* This is done anytime we want the actual values (rather than the
* accumulated dose over a 2-minute period).
* Inputs:
 Formal name Type
                                  Purpose
* Return value:
 Type Purpose
  tBvte
           0 = Success
         -1 = Error: NULL pointer
         -2 = Error: Invalid Dosimeter number
    *************************
tByte read_dosimeter_all( tByte mode2 )
```

```
tWord I = 0:
 tWord m = 0:
 tWord h = 0;
 tByte i = 0;
 ReadAllIsRunning = 1;
 if ((RunOnce == 0)) {
  // Do this once at startup and each mode change
  RunOnce = 1:
  count = 0;
  tick = 0:
 }
 // Burn one ADC operation for each device to set up read channel
 sample adc fast2(0x00); // Set the first ADC0 chan to read DOS1 LOW
 sample adc fast2(0x15); // Set the first ADC1 chan to read DOS3 LOW
 for (i = 0; i < 16; i++) {
  I += sample adc fast2(0x00);
 sample adc fast2(0x01);
 for (i = 0; i < 16; i++) {
  m += sample adc fast2(0x01);
 sample adc fast2(0x02);
 for (i = 0; i < 16; i++) {
  h += sample adc fast2(0x02);
 sample adc fast2(0x03);
 m = (m >> 4); // Don't shift h and I
#ifdef DEBUG
 I = m = h = 0;
#endif // DEBUG
 // The following (commented out) is what we want to accomplish
 // However, this method involves several long functions calls and
 // requires 454 uS to complete.
 //dos[0] = ((tLong )h << 20) | ((tLong )m << 8) | ((tLong )l >> 4);
 // However, There is not time during the interrupt service routine
 // to perform all 9 ADC operations and this calculation (times three).
 // This is a hack that accomplishes the same result and only takes
```

```
// 30.5 uS to complete!! This is the magic of hand coding.
 // The next two lines are commented out because they are offset by
 // the collection of 16 samples.
 // h = h << 4;
 // | = | << 4:
*(tByte *)(dos) = *(tByte *)(&h);
 *((tByte *)dos+1) = (*(((tByte *)&h)+1) & 0xF0) | (*(tByte *)(&m) & 0x0F);
 *((tByte *)dos+2) = *(((tByte *)&m)+1);
 *((tByte *)dos+3) = *(tByte *)(&I);
 // Zero local values
 I = m = h = 0:
 // Read DOS2 LOW sixteen times
 for (i = 0; i < 16; i++)
  I += sample adc fast2(0x03);
 sample adc fast2(0x04);
 // Read DOS2 MID sixteen times
 for (i = 0; i < 16; i++) {
  m += sample adc fast2(0x04);
 sample adc fast2(0x05);
 // Read DOS2 HI sixteen times
 for (i = 0; i < 16; i++) {
  h += sample adc fast2(0x05);
 m = (m >> 4); // Don't shift h and I
 // If we are in Analysis Mode 2, we need to read subcommutated values
 if (mode2 == 1) {
  sample adc fast2( adc ch mode2[0][count] ); // "Decision Stage 0"
 } else {
  sample adc fast2(0x00);
#ifdef __DEBUG__
 h = m = 1 = 0:
#endif // DEBUG
 *(tByte *)(dos+4) = *(tByte *)(&h);
```

```
*((tByte *)dos+5) = (*(((tByte *)&h)+1) & 0xF0) | (*(tByte *)(&m) & 0x0F);
 *((tByte *)dos+6) = *(((tByte *)&m)+1);
 *((tByte *)dos+7) = *(tByte *)(&I);
 // Zero local values
 I = m = h = 0;
 for (i = 0; i < 16; i++) {
  I += sample_adc_fast2( 0x15 );
 sample adc fast2(0x16);
 for (i = 0; i < 16; i++) {
  m += sample adc fast2(0x16);
 sample adc fast2(0x17);
 for (i = 0; i < 16; i++) {
  h += sample adc fast2(0x17);
 m = (m >> 4); // Don't shift h and I
 if (mode2 == 1) {
  sample adc fast2( adc ch mode2[1][count] ); // "Decision Stage 1"
 } else {
  sample adc fast2(0x15);
 #ifdef DEBUG
 I = m = h = 0;
#endif // DEBUG
 *(tByte *)(dos+8) = *(tByte *)(&h);
 *((tByte *)dos+9) = (*(((tByte *)&h)+1) & 0xF0) | (*(tByte *)(&m) & 0x0F);
 *((tByte *)dos+10) = *(((tByte *)&m)+1);
 *((tByte *)dos+11) = *(tByte *)(&I);
 // Perform one "extra" ADC per tick of the System Timer
 // Truncate the current value to 8 bits
 if ( mode2 == 1) {
  curr val = sample adc fast2( adc ch mode2[2][count] ); // "Decision Stage 2"
 }
#ifdef DEBUG
 curr val = 0x0A5A;
#endif // DEBUG
 if (mode2 == 1)
```

```
// Read the next 'miscellaneous' channel
  switch (count) {
   case 0:
     ps 15V = compute avg( curr val, ps 15V );
    break;
   case 1:
    ps 5V = compute avg( curr val, ps 5V );
    break;
   case 2:
    temps[0] = compute avg( curr val, temps[0] );
    break;
   case 3:
    temps[1] = compute avg( curr val, temps[1] );
    break;
   case 4:
    temps[2] = compute avg( curr val, temps[2] );
    break:
   default:
  }
  count++;
  // Count goes: 0, 1, 2, 3, 4, 0, 1, 2, 3, 4, ...
  if (count == 5) count = 0; // May be superfluous
 ReadAllIsRunning = 0;
 // Return no error
 return 0;
* read dosimeter low()
* Reads only the value of the low channel of all dosimeters, truncates
* the value into an 8 bit value, checks for a rollover condition, and
* adds the current (truncated) value to the 32-bit value (in the
* form: High:12, Med:12, Low:8
* Inputs:
  None
* Return value:
 Type
            Purpose
 tBvte
            0 = Success
```

```
tByte read dosimeter low()
#ifdef DEBUG
 #define DUMMY INC1 321
 #define DUMMY INC2 20
 #define DUMMY INC3 14
 static tWord dummy val1 = 0;
 static tWord dummy val2 = 0;
 static tWord dummy val3 = 0;
#endif // DEBUG
 if (RunOnce == 0) {
  // Do this once at startup and each mode change
  RunOnce = 1;
  count = 0;
  tick = 0;
  sample adc fast2(0x00); // Set the first ADC0 chan for present mode
  sample adc fast2(0x15); // Set the first ADC1 chan for present mode
 curr val = sample adc fast2( adc ch[count++] );
#ifdef DEBUG
  dummy val1 = (dummy val1 + DUMMY INC1) & (tWord )0x0FFF;
  curr val = dummv val1:
#endif // DEBUG
 curr val = curr val >> 4;
 if (check rollover((tByte )curr val, (tByte)dos[0])) {
  dos[0] = ((dos[0] \& 0xFFFFFF00) | (tLong) curr val) + 256;
 } else {
  dos[0] = ((dos[0] \& 0xFFFFFF00) | (tLong) curr_val);
 curr val = sample adc fast2( adc ch[count++]);
 #ifdef DEBUG
  dummy val2 = (dummy val2 + DUMMY INC2) & (tWord )0x0FFF;
  curr val = dummy_val2;
#endif // __DEBUG___
 curr val = curr val >> 4;
 if (check_rollover((tByte_)curr_val, (tByte)dos[1])) {
  dos[1] = ( (dos[1] & 0xFFFFFF00) | (tLong )curr_val) + 256;
```

```
} else {
  dos[1] = ((dos[1] \& 0xFFFFFF00) | (tLong) curr val);
 curr val = sample adc fast2( adc ch[count++] );
#ifdef DEBUG
  dummy_val3 = (dummy_val3 + DUMMY_INC3) & (tWord )0x0FFF;
  curr val = dummy val3;
#endif // DEBUG
 curr val = curr val >> 4;
 if (check_rollover((tByte_)curr_val, (tByte)dos[2])) {
  dos[2] = ((dos[2] \& 0xFFFFFF00) | (tLong) curr val) + 256;
 } else {
  dos[2] = ((dos[2] \& 0xFFFFFF00) | (tLong) curr val);
 // Truncate the current value to 8 bits
 curr val = sample adc fast2( adc ch[count++] );
#ifdef DEBUG
 curr val = 0x0A5A;
#endif // DEBUG
 // Read the next 'miscellaneous' channel
 switch (tick) {
  case 0:
   ps 15V = compute avg( curr val, ps 15V );
   break;
  case 1:
   ps 5V = compute avg( curr val, ps 5V );
   break;
  case 2:
   temps[0] = compute_avg( curr_val, temps[0] );
   break;
  case 3:
   temps[1] = compute avg( curr val, temps[1] );
   break:
  case 4:
   temps[2] = compute_avg( curr_val, temps[2] );
   break:
  default:
   //tick = 0:
```

```
tick++; if (tick == 5) tick = 0;
 if (count == 20) count = 0;
 // Return no error
 return 0;
tByte check rollover(tByte val, tByte old val)
 /* Rollover condition:
     Old value: 11xx xxxx
     New value: 00xx xxxx
 if ( ((old val & 0xC0) == 0xC0) && ((val & 0xC0) == 0x00) )
  return 1; // Rollover detected
 else
  return 0;
tWord compute avg( tWord x, tWord xmean )
 tWord xtemp;
 if (k[tick] == 0) {
  k[tick] = 1;
  xtemp = x << 4;
 } else {
  xtemp = xmean >> 1; // xtemp = 1/2 * xmean
  xtemp += xmean >> 2; // xtemp = 3/4 * xmean
  xtemp += xmean >> 3; // xtemp = 7/8 * xmean
  xtemp += xmean >> 4; // xtemp = 15/16 * xmean
                // x temp = (15/16 * x mean) + x
  xtemp += x;
 return xtemp;
```

#### **Dosimeter.c File Reference**

#include "main.h"

#### Macros

#define CAL\_PULSE\_WIDTH 17

### **Functions**

- void Init\_INSTRUMENT CONTROL (void)
- void SysTimerSetupFast (void)
- void SysTimerSetupSlow (void)
- void SystemTick (void)
- void TSK DoCal ()
- void initialize\_normal\_mode (void)
- void initialize\_startup\_mode (void)
- void ChangeToAnalysisMode2 (void)
- void ChangeToAnalysisMode1 (void)
- void TSK\_DoADC (void)

### **Variables**

- Status1 type idata Status1
- Status2 type idata Status2
- MCF\_type idata MCF
- tLong idata dos [3]
   INSTRUMENT CONTROL Dosimeter Telemetry Application (Main module) (Version 2.0: Flight Software)
- tLong idata dos\_zero [3]
- tLong idata cal\_pre [3]
- tLong idata cal post [3]
- tWord idata dos\_livetime [3]
- tLong idata TickCount
- tLong idata TotalTickCount
- tByte idata HourCount
- bit TelemetryTick
- bit ADC\_Start
- bit CalRunning
- bit ReadAllIsRunning
- bit CalMode
- bit RunOnce
- bit GSE
- bit INSTRUMENT CONTROL\_Enable
- bit **Dos1TurnOn**
- bit Dos2TurnOn
- bit Dos3TurnOn

### tLong idata RxTimer

**Macro Definition Documentation** 

#define CAL PULSE WIDTH 17

Definition at line 5 of file Dosimeter.c.

**Function Documentation** 

void ChangeToAnalysisMode1 (void )

Definition at line 279 of file Dosimeter.c.

void ChangeToAnalysisMode2 (void )

Definition at line 269 of file Dosimeter.c.

void Init\_INSTRUMENT CONTROL (void )

Definition at line 31 of file Dosimeter.c.

void initialize\_normal\_mode (void )

Definition at line 210 of file Dosimeter.c.

void initialize\_startup\_mode (void )

Definition at line 239 of file Dosimeter.c.

void SystemTick (void )

Definition at line 113 of file Dosimeter.c.

void SysTimerSetupFast (void )

Definition at line 57 of file Dosimeter.c.

void SysTimerSetupSlow (void )

Definition at line 85 of file Dosimeter.c.

```
void TSK_DoADC (void )
```

Definition at line 289 of file Dosimeter.c.

void TSK\_DoCal ()

Definition at line 162 of file Dosimeter.c.

### **Variable Documentation**

bit ADC\_Start

Definition at line 47 of file MAIN.C.

tLong idata cal\_post[3]

Definition at line 36 of file MAIN.C.

tLong idata cal\_pre[3]

Definition at line 35 of file MAIN.C.

bit CalMode

Definition at line 54 of file MAIN.C.

bit CalRunning

Definition at line 53 of file MAIN.C.

tLong idata dos[3]

INSTRUMENT CONTROL Dosimeter Telemetry Application (Main module) (Version 2.0: Flight Software)

This code implements the full INSTRUMENT CONTROL dosimeter sensor, including all message formatting, data processing, and utility functions (ADC, CRC, ...)

Version Rev. 1.0 Created from the code written by Brian Zufelt for the development board and by code written by me for the EU model.

Chip type: Aeroflex UTMC UT69RH051 Program type: Firmware Core Clock

frequency: 16.129000 MHz

Definition at line 33 of file MAIN.C.

bit Dos1TurnOn

Definition at line 85 of file MAIN.C.

bit Dos2TurnOn

Definition at line 86 of file MAIN.C.

bit Dos3TurnOn

Definition at line 87 of file MAIN.C.

tWord idata dos\_livetime[3]

Definition at line 37 of file MAIN.C.

tLong idata dos\_zero[3]

Definition at line 34 of file MAIN.C.

bit GSE

Definition at line 82 of file MAIN.C.

tByte idata HourCount

MCF\_type idata MCF

Definition at line 80 of file MAIN.C.

bit ReadAllIsRunning

Definition at line 81 of file MAIN.C.

bit INSTRUMENT CONTROL\_Enable

Definition at line 50 of file MAIN.C.

bit RunOnce

Definition at line 84 of file MAIN.C.

# tLong idata RxTimer

Definition at line 60 of file MAIN.C.

Status1\_type idata Status1

Definition at line 78 of file MAIN.C.

Status2\_type idata Status2

Definition at line 79 of file MAIN.C.

bit TelemetryTick

Definition at line 46 of file MAIN.C.

tLong idata TickCount

Definition at line 57 of file MAIN.C.

tLong idata TotalTickCount

Definition at line 58 of file MAIN.C.

```
// Dosimeter.c : Dosimeter-related function implementations
#include "main.h"
#define CAL PULSE WIDTH 17
extern Status1 type idata Status1;
extern Status2 type idata Status2;
extern MCF type idata MCF;
extern tLong idata dos[3];
extern tLong idata dos zero[3];
extern tLong idata cal pre[3];
extern tLong idata cal post[3];
extern tWord idata dos livetime[3];
extern tLong idata TickCount;
extern tLong idata TotalTickCount;
extern tByte idata HourCount;
extern bit TelemetryTick;
extern bit ADC Start;
extern bit CalRunning;
extern bit ReadAllIsRunning;
extern bit CalMode;
extern bit RunOnce:
extern bit GSE;
extern bit INSTRUMENT CONTROL Enable;
extern bit Dos1TurnOn:
extern bit Dos2TurnOn:
extern bit Dos3TurnOn;
extern tLong idata RxTimer;
void Init INSTRUMENT CONTROL(void)
{
              //7654 3210
              // -----
 P1 = 0x7F;
                 //0111 1111
              //
                      +-+-+- Dosimeters powered off
              // +---+---- ADCs 1,2 disabled
              // +----- SCLK high
              // +----- MISO set for input (high)
              // +----- MOSI set low
              //7654 3210
              // -----
 P3 = P3 \mid 0x2C; // X X 1 X 1 1 X X
                         +-- RxD controlled by 8051
```

```
//
                          +---- TxD controlled by 8051
               II
                         +----- CAL set high (disabled)
               //
                       +----- INT 1 set for input (high)
               //
                      +----- EEPROM RST CTRL - leave unchanged
                    +----- MEM MAP set high (lower 64KB bank selected)
               // +-+---- RD, WR controlled by 8051 (high)
 // We leave the "Final" bit set for every packet
 Final = 1;
void SysTimerSetupFast( void )
 // Timer 2 is to be used as a system tick timer (in the final system)
 // If we use this timer to generate a tick every 2 msec, that will
 // require a reload value that is 65536 - (0.002 seconds * Tclk).
 // For a 16.129 MHz oscillator, Finst = 16129000/12 = 1.344083 MHz
 // This results in Tinst = 744 ns. Therefore 1 ms = 1,344 instructions.
 // For a system timer interval of M msecs, we need M * 1344.
 // For 4 ms, the reload timer needs to be 65536 - 5376 = 60160.
 // In hexadecimal, this is: 0xEB00
 ET2
        = 0:
 TR2 = 0:
 T2CON = 0x04; // Load the T2 timer control register:
            // T2 Run on, no mode bits to sweat
 T2MOD = 0x00; // Timer mode control
        = 0xEB; // Load the upper byte
 RCAP2H = 0xEB; // Upper byte of the reload value
 TL2 = 0x00: // Load the lower byte
 RCAP2L = 0x00; // Load the lower byte
 // Enable the T2 interrupt
 ET2
        = 1:
 // Start the timer running
 TR2
}
void SysTimerSetupSlow( void )
 // Timer 2 is to be used as a system tick timer (in the final system)
 // If we use this timer to generate a tick every 20 msec, that will
 // require a reload value that is 65536 - (0.02 seconds * Tclk).
 // For a 16.129 MHz oscillator, Finst = 16129000/12 = 1.344083 MHz
```

```
// This results in Tinst = 744 ns. Therefore 1 ms = 1.344 instructions.
 // For a system timer interval of M msecs, we need M * 1344.
 // For 32ms, the reload timer needs to be 65536 - 43,008 = 22,528.
 // In hexadecimal, this is: 0x5800
 ET2 = 0:
 TR2 = 0:
 T2CON = 0x04; // Load the T2 timer control register:
          // T2 Run on, no mode bits to sweat
 T2MOD = 0x00; // Timer mode control
 TH2 = 0x58; // Load the upper byte
 RCAP2H = 0x58; // Upper byte of the reload value
 TL2 = 0x00; // Load the lower byte
 RCAP2L = 0x00; // Load the lower byte
 // Enable the T2 interrupt
 ET2 = 1:
 // Start the timer running
 TR2
       = 1;
void SystemTick(void) interrupt INTERRUPT T2 Overflow
 // Clear the T2 overflow flag
 TF2 = 0:
 // Increment the tick count
 if (!INSTRUMENT CONTROL Enable) return;
 if (AnalysisMode == 0) {
  TickCount += 2;
  TotalTickCount += 2:
 } else {
  TickCount += 16;
  TotalTickCount += 16;
 // Increment each livetime counter once every 8.7381333333 minutes.
 if (dos1 pwr) {
  1111
   dos livetime[0]++;
 } else {
  dos livetime[0] = 0;
```

```
if (dos2 pwr) {
  1111
   dos livetime[1]++;
 } else {
  dos livetime[1] = 0;
 if (dos3 pwr) {
 1111
   dos livetime[2]++;
 } else {
  dos_livetime[2] = 0;
 if (CalRunning) return;
 if (ReadAllIsRunning) return;
 if (TelemetryTick) return;
 // Synchonize pins with status
 TDYN0 = dos1 pwr;
 TDYN1 = dos2_pwr;
 TDYN2 = dos3 pwr;
 // This will trigger a new ADC sampling cycle (regardless of the mode)
 ADC Start = 1;
}
void TSK DoCal()
 tWord i;
 ContentID = CAL CONTENT;
 CalRunning = 1;
 // Transfer the most recent values (in dos[]) to cal pre[]
 RunOnce = 0:
 read dosimeter all(0);
 cal pre[0] = dos[0];
cal_pre[1] = dos[1];
 cal\_pre[2] = dos[2];
 // Run CAL pulses
 for (i = 0; i < 50000; i++) {
  pulse_cal( CAL_PULSE_WIDTH );
```

```
}
 // Set the Cmd history to '0000', VREF Frame to "15V & 5V"
 // Clear CmdRcvd and CmdValid flags.
 Status2.value = 0x00:
 // Read the data from the three dosimeters
 RunOnce = 0; // Want to start at the beginning of the aux ADC channels
 read dosimeter all(0);
 cal post[0] = dos[0];
 cal post[1] = dos[1];
 cal post[2] = dos[2];
 // End of Calibration process
 CalRunning = 0;
/*********************
* initialize normal mode()
* _____
* This sets up the normal-mode (default) behavior
* It really is a script of several common function calls.
* Inputs: None
* Output: None
* Assumptions: It is assumed that the device is being switched to
         operate in a normal mode (at startup or from some
         other mode)
  **********************************
void initialize normal mode(void)
{
 // Start by initializing the normal status.
 // Status1: Field
                  Value
                                   Bit(s)
 II
 //
         Sample Mode
                           1 (High)
                                      7
 //
         Content ID
                         01 (Normal) 6,5
 //
                          1 (on)
         Dosimeter #1
                                    4
                                    3
 II
         Dosimeter #2
                          1 (on)
         Dosimeter #3
                                    2
 //
                          1 (on)
         Analysis Mode
                           0 (Mode1)
 II
                                       1
 //
         EEPROM Error
                            1 (Good)
                                        0
 II
```

```
Status1.value = 0xBD;
 // Get out of GSE mode
 GSE = 0;
 // Set the Cmd history to '0000', VREF Frame to "15V & 5V"
 // Clear CmdRcvd and CmdValid flags.
 Status2.value = 0x00;
 RunOnce = 0;
 // Perform initial reads of all three dosimeters
 read dosimeter all(0);
}
void initialize startup mode(void)
 // Start by initializing the normal status.
 // Status1: Field
                          Value
                                    Bit(s)
 II
 //
         Sample Mode
                            1 (High)
                                        7
 //
         Content ID
                          01 (Normal) 6,5
         Dosimeter #1
                           0 (off)
                                      4
 II
         Dosimeter #2
                           0 (off)
                                      3
 II
                                      2
 //
         Dosimeter #3
                           0 (off)
 //
                            0 (Mode1)
         Analysis Mode
 //
         EEPROM Error
                             1 (Good)
                                         0
 //
 Status1.value = 0xA1;
 // Get out of GSE mode
 GSE = 0;
 // Set the Cmd history to '0000', VREF Frame to "15V & 5V"
 // Clear CmdRcvd and CmdValid flags.
 Status2.value = 0x00;
#ifdef DEBUG
 Status1.value = 0x21:
 GSE = 1;
#endif // DEBUG
 RunOnce = 0;
```

```
void ChangeToAnalysisMode2( void )
 // Change to the 16 ms timer interval required for Analysis Mode 2
 SysTimerSetupSlow();
 TickCount = 0:
 dos[0] = 0;
 dos[1] = 0;
 dos[2] = 0;
void ChangeToAnalysisMode1( void )
 // Change to the 2 ms timer interval required for Analysis Mode 1
 SysTimerSetupFast();
 TickCount = 0;
 dos[0] = 0;
 dos[1] = 0;
 dos[2] = 0;
void TSK DoADC( void )
  if (AnalysisMode == 0)
  if (Dos1TurnOn) {
   dos zero[0] = dos[0] = 0;
   Dos1TurnOn = 0;
  if (Dos2TurnOn) {
   dos zero[1] = dos[1] = 0;
   Dos2TurnOn = 0;
  if (Dos3TurnOn) {
   dos zero[2] = dos[2] = 0;
   Dos3TurnOn = 0;
  read dosimeter low();
 } else {
  read dosimeter all(1);
  if (Dos1TurnOn) {
   dos zero[0] = dos[0];
   Dos1TurnOn = 0;
  if (Dos2TurnOn) {
   dos_zero[1] = dos[1];
```

```
Dos2TurnOn = 0;
}
if (Dos3TurnOn) {
  dos_zero[2] = dos[2];
  Dos3TurnOn = 0;
```

Interface.c File Reference #include "main.h"

### **Functions**

- tWord **crc16** (unsigned char \*pData, unsigned char len)
- unsigned int **SLIP** (unsigned char \*packet, unsigned int Packet\_len)
- unsigned int UNSLIP (unsigned char \*packet, unsigned int Packet len)

#### **Function Documentation**

tWord crc16 (unsigned char \* pData, unsigned char len)

Definition at line 25 of file Interface.c.

unsigned int SLIP (unsigned char \* packet, unsigned int Packet\_len)

Definition at line 84 of file Interface.c.

unsigned int UNSLIP (unsigned char \* packet, unsigned int Packet\_len)

Definition at line 122 of file Interface.c.

```
/********************************
Project: INSTRUMENT CONTROL Dosimeter (Interface.c)
Version: 0.1 EU (Engineering Unit)
Date : 2/20/2013
Author: Brian Zufelt
Company: COSMIAC/UNM
Comments:
This source provides all the functions to format the
output messages through the serial interface.
************************************
#include "main.h"
/********************************
      Send a pointer to an array and returns a 16-bit CRC
      Check.
      Return: 16-bit CRC value
************************************
tWord crc16(unsigned char *pData, unsigned char len)
 unsigned int x = 0xFFFF;
 unsigned char *p = pData;
 unsigned char ch = *p;
 while (len) {
  x ^= ch:
  // Unrolling this loop results in a 27% reduction in processing time.
  if (x & 1)
   x = (x >> 1) ^ 0x8408;
  else
   x = (x >> 1);
  if (x & 1)
   x = (x >> 1) ^ 0x8408;
  else
   x = (x >> 1);
  if (x & 1)
   x = (x >> 1) ^ 0x8408;
  else
   x = (x >> 1);
```

```
if (x & 1)
   x = (x >> 1) ^ 0x8408;
  else
   x = (x >> 1);
  if (x & 1)
   x = (x >> 1) ^ 0x8408;
  else
   x = (x >> 1);
  if (x & 1)
   x = (x >> 1) ^ 0x8408;
  else
   x = (x >> 1);
  if (x & 1)
   x = (x >> 1) ^ 0x8408;
  else
   x = (x >> 1);
  if (x & 1)
   x = (x >> 1) ^ 0x8408;
  else
   x = (x >> 1);
  len--; p++; ch = (char)*p;
 return x;
The SLIP Function is Encapsulates the SLIP framing to a given
      packet.
      Returns: New packet length
      NOTE: At least packet length + 2 bytes are required for start/stop
      char. Additional size requirements of the buffer depend on the occurance
      of FEND or FESC within the data packet.
unsigned int SLIP(unsigned char *packet, unsigned int Packet len){
      int i = 0, j=0;
                                                                  //general
counter
     for(i=Packet len;i>0;i--) {
                                                      // Shift packet 1 byte to the
right
```

```
packet[i] = packet[i-1];
      }
       Packet len += 2;
       //increase packet size by 2 to add new characters
       packet[0] = FEND;
                                                                                    //add
start char
       packet[Packet len-1] = FEND;
                                                               //add end char
       for(i=(Packet len-2);i>1;i--)
                                         // i<1 because packet[0] has to == FEND and
packet[Packet len] == FEND
              if(packet[i] == FEND)
  {
                    for(j = (Packet_len); j != i; j--)
   {
                            packet[j] = packet[j-1];
                     Packet len++;
      // increase Packet length size
                     packet[i] = FESC;
                     packet[i+1] = TFEND;
             else if(packet[i] == FESC)
  {
                     for(j = (Packet len); j != i; j--)
   {
                            packet[j] = packet[j-1];
                     Packet len++:
      // increase Packet length size
                     packet[i] = FESC;
                     packet[i+1] = TFESC;
             }
 }
       return Packet len;
                                   //return new packet length
}
unsigned int UNSLIP( unsigned char *packet, unsigned int Packet len )
 int i, j = 0;
 for (i = 0; i < Packet len - 2; i++) {
  if (packet[i] == FESC) {
   if (packet[i+1] == TFEND) {
                      Approved for Public Release; Distribution is unlimited
```

```
packet[i] = FEND;
for (j = i+1; j < Packet_len -1; j++) {
    packet[j] = packet[j+1];
    }
    Packet_len--;
} else if (packet[i+1] == TFESC) {
    packet[i] = FESC;
    for (j = i+1; j < Packet_len -1; j++) {
        packet[j] = packet[j+1];
    }
    Packet_len--;
} else {
    // Error condition! Should never reach here...
    return 0;
}
}
return Packet_len;</pre>
```

#### **MAIN.C** File Reference

#include "main.h"

#### **Functions**

void main (void)

#### **Variables**

- \*tLong idata dos [3] = 0
   INSTRUMENT CONTROL Dosimeter Telemetry Application (Main module) (Version 2.0: Flight Software)
- tLong idata dos\_zero [3] = 0
- tLong idata **cal\_pre** [3] = 0
- tLong idata cal\_post [3] = 0
- tWord idata dos\_livetime [3] = 0
- tWord idata ps\_15V
- tWord idata ps\_5V
- tWord idata temps [3]
- tWord idata FrameCounter = 0
- bit **TelemetryTick** = 0
- bit **ADC** Start = 0
- bit **ResetImminent** = 0
- bit **TxEnable** = 0
- bit INSTRUMENT CONTROL Enable = 0
- bit **CalRunning** = 0
- bit CalMode = 1
- tLong idata TickCount = 0
- tLong idata TotalTickCount = 0
- tWord idata PktCnt\_Cal = 0
- tLong idata **RxTimer** = 0xFFFFFFF
- tByte idata XmitLength = 0
- tByte idata **DataBuff** [48]
- tByte idata **AckBuff** [14]
- tByte idata \* pXmitPtr
- tByte idata RecvLength = 6
- MessageQueue msgQueue
- tByte idata **RecvBuff** [10]
- tByte idata \* pRecvPtr
- Status1 type idata Status1
- Status2 type idata Status2
- MCF type idata MCF
- bit ReadAllIsRunning = 0
- bit GSE = 0
- bit **Poll** = 0

- bit **RunOnce** = 0
- bit **Dos1TurnOn** = 0
- bit **Dos2TurnOn** = 0
- bit **Dos3TurnOn** = 0
- tByte code adc\_ch\_mode2 [3][5]
- tByte code adc\_ch []

#### **Function Documentation**

## void main (void )

Definition at line 108 of file MAIN.C.

#### **Variable Documentation**

## tByte idata AckBuff[14]

Definition at line 65 of file MAIN.C.

## tByte code adc\_ch[]

```
Initial value:= { 0x03, 0x00, 0x10, 0x15, 0x03, 0x06, 0x15, 0x00, 0x03, 0x00, 0x11, 0x15, 0x03, 0x00, 0x12, 0x15, 0x03, 0x00, 0x14, 0x15 }
```

Definition at line 104 of file MAIN.C.

## tByte code adc\_ch\_mode2[3][5]

Definition at line 91 of file MAIN.C.

```
bit ADC_Start = 0
```

Definition at line 47 of file MAIN.C.

```
tLong\ idata\ cal\_post[3] = 0
```

Definition at line 36 of file MAIN.C.

## tLong idata cal\_pre[3] = 0

Definition at line 35 of file MAIN.C.

bit CalMode = 1

Definition at line 54 of file MAIN.C.

bit CalRunning = 0

Definition at line 53 of file MAIN.C.

tByte idata DataBuff[48]

Definition at line 64 of file MAIN.C.

\*  $tLong\ idata\ dos[3] = 0$ 

INSTRUMENT CONTROL Dosimeter Telemetry Application (Main module) (Version 2.0: Flight Software)

This code implements the full INSTRUMENT CONTROL dosimeter sensor, including all message formatting, data processing, and utility functions (ADC, CRC, ...)

Version Rev. 1.0 Created from the code written by Brian Zufelt for the development board and by code written by me for the EU model.

Chip type: Aeroflex UTMC UT69RH051 Program type: Firmware Core Clock frequency: 16.129000 MHz

Definition at line 33 of file MAIN.C.

bit Dos1TurnOn = 0

Definition at line 85 of file MAIN.C.

bit Dos2TurnOn = 0

Definition at line 86 of file MAIN.C.

bit Dos3TurnOn = 0

Definition at line 87 of file MAIN.C.

tWord idata dos\_livetime[3] = 0

Definition at line 37 of file MAIN.C.

tLong idata dos\_zero[3] = 0

Definition at line 34 of file MAIN.C.

tWord idata FrameCounter = 0

Definition at line 43 of file MAIN.C.

bit GSE = 0

Definition at line 82 of file MAIN.C.

MCF\_type idata MCF

Definition at line 80 of file MAIN.C.

MessageQueue msgQueue

Definition at line 68 of file MAIN.C.

tWord idata PktCnt\_Cal = 0

Definition at line 59 of file MAIN.C.

bit Poll = 0

Definition at line 83 of file MAIN.C.

tByte idata\* pRecvPtr

Definition at line 75 of file MAIN.C.

tWord idata ps\_15V

Definition at line 38 of file MAIN.C.

tWord idata ps\_5V

Definition at line 39 of file MAIN.C.

```
tByte idata* pXmitPtr
   Definition at line 66 of file MAIN.C.
bit ReadAllIsRunning = 0
   Definition at line 81 of file MAIN.C.
tByte idata RecvBuff[10]
   Definition at line 73 of file MAIN.C.
tByte idata RecvLength = 6
   Definition at line 67 of file MAIN.C.
bit ResetImminent = 0
   Definition at line 48 of file MAIN.C.
bit INSTRUMENT CONTROL_Enable = 0
   Definition at line 50 of file MAIN.C.
bit RunOnce = 0
   Definition at line 84 of file MAIN.C.
tLong idata RxTimer = 0xFFFFFFF
   Definition at line 60 of file MAIN.C.
Status1_type idata Status1
```

Definition at line 78 of file MAIN.C.

Status2\_type idata Status2

Definition at line 79 of file MAIN.C.

bit TelemetryTick = 0

Definition at line 46 of file MAIN.C.

# tWord idata temps[3] Definition at line 40 of file MAIN.C. tLong idata TickCount = 0 Definition at line 57 of file MAIN.C. tLong idata TotalTickCount = 0 Definition at line 58 of file MAIN.C. bit TxEnable = 0 Definition at line 49 of file MAIN.C. tByte idata XmitLength = 0 Definition at line 63 of file MAIN.C. \_\_\_\_\_\_ //! //! \brief INSTRUMENT CONTROL Dosimeter Telemetry Application (Main module) //! (Version 2.0: Flight Software) //! This code implements the full INSTRUMENT CONTROL dosimeter sensor, //! including all message formatting, data processing, and //! utility functions (ADC, CRC, ...) //! \*\*\*\*\*\*\*\* //! Version Rev. //! 1.0 Created from the code written by Brian Zufelt for //! the development board and by code written by me for the EU model. //! \*\*\*\*\*\*\*\*\*\*\*\*\*\*\* //! Chip type : Aeroflex UTMC UT69RH051 //! Program type : Firmware

Approved for Public Release; Distribution is unlimited

//! Core Clock frequency : 16.129000 MHz

```
Project: INSTRUMENT CONTROL Dosimeter Telemetry Application (Main.c)
Version: 1.0 FH (Flight Hardware)
Date : 07/18/2013
Company: COSMIAC/UNM
**************************
#include "main.h" // Global header
/* Global storage for measurements */
tLong idata dos[3] = 0;
                        // Contains the actual dosimeter values
tLong idata dos zero[3] = 0; // Baseline values for the three dosimeters
tLong idata cal pre[3] = 0; // Contains the values at power on.
tLong idata cal post[3] = 0; // Contains the intermediate values (dos[] + dose since last
update)
tWord idata dos livetime[3] = 0; // Total running time for each dosimeter.
tWord idata ps 15V; // 15V line
tWord idata ps_5V; // 5V line
tWord idata temps[3]; // Temperatures
// Global frame counter
tWord idata FrameCounter = 0; // The frame counter - must be zero'ed out on
reset/power-up
// Command/Status
bit TelemetryTick = 0; // This will be '1' whenever we are sending telemetry data
bit ADC_Start = 0; // This is a flag set by the SysTimerXXX interrupt routine.
bit ResetImminent = 0; // This will likely not be used (the "Reset Imminent" cmd is
not implemented)
bit TxEnable = 0; // If this is clear, we continue to measure/accumulate dose, but
don't report
bit INSTRUMENT CONTROL Enable = 0; // This flag keeps the instrument from
starting to run until the first command
// Calibration interval counter
bit CalRunning = 0; // '1' if the CAL pulses are being generated
bit CalMode = 1; // CalMode = 1 --> perform weekly calibration and reset
dosimeters
// Tracking time for interrupt interval
tLong idata TickCount = 0; // Counts 2ms intervals to trigger events
tLong idata TotalTickCount = 0;
tWord idata PktCnt_Cal = 0;
```

tLong idata RxTimer = 0xFFFFFFFF; // Initialize to high end of range

```
// Serial comm buffers
tByte idata XmitLength = 0; // If this value is non-zero, there is data to transmit
tByte idata DataBuff[48]; // Data block containing chars to be xmit'd
tByte idata AckBuff[14]; // Data block for Ack packet chars
tByte idata *pXmitPtr; // Pointer for iterating through the xmit buffer
tByte idata RecvLength = 6; // Command receive length
MessageQueue msgQueue; // Contains the pointers and lengths for data / ack
packets
#ifdef DEBUG
   tByte idata RecvBuff[10] = \{0x56, 0x11, 0xA2, 0x7E, 0x44, 0x52, 0x00, 
0x00;
#else
   tByte idata RecvBuff[10];
#endif // DEBUG
tByte idata *pRecvPtr;
// Status bytes and Command/Status flags
Status1 type idata Status1;
Status2 type idata Status2;
MCF type idata MCF;
bit ReadAllIsRunning = 0;
bit GSE = 0:
bit Poll = 0;
bit RunOnce = 0;
bit Dos1TurnOn = 0:
bit Dos2TurnOn = 0;
bit Dos3TurnOn = 0:
// This 2D array contains the ADC dev/ch sequence for Analysis Mode 2
// (The first index is the "stage", the second is where we are in <count>)
tByte code adc ch mode2[3][5] =
                          { // (1) (2) (3) (4) (5)
                                 { 0x00, 0x06, 0x00, 0x00, 0x00 }, // "Stage 0"
                                 { 0x10, 0x15, 0x11, 0x12, 0x14 }, // "Stage 1"
                                 { 0x15, 0x00, 0x15, 0x15, 0x15 } // "Stage 2"
                          };
// This 1D array contains the ADC dev/ch sequence for Analysis Mode 1
// (There are four measurements per timer tick:
//
                                    Dos1Low.
//
                                    Dos2Low.
//
                                    Dos3Low.
```

```
one of {+15V, +5V, Temp1, Temp2, Temp3}
tByte code adc ch[] = \{ 0x03, 0x00, 0x10, 0x15, 0x03, 0x06, 0x15, 0x03, 0x06, 0x15, 0x15
                                       0x00, 0x03, 0x00, 0x11, 0x15, 0x03, 0x00,
                                       0x12,
                                                                       0x15, 0x03, 0x00, 0x14, 0x15};
void main(void){
   Init INSTRUMENT CONTROL();
                                                                                                                           // Configure pins for start-up:
   SysTimerSetupFast(); // Start the system tick timer com_initialize (); // initialize interrupt driven serial I/O com_baudrate (4800); // setup for 4800 baud
   pXmitPtr = (tByte *)DataBuff; // Initialize the transmit pointer
   pRecvPtr = (tByte *)RecvBuff; // Initialize the receive pointer
   msqQueue.nDataLength = 0;
   msgQueue.nAckLength = 0;
#ifdef DEBUG
   FakeData();
#endif // DEBUG
   // Enable the T2 interrupt, start the timer, and enable global interrupts
   ET2 = 1;
   TR2 = 1:
                  EA = 1;
   // Make sure the instrument comes up in an inactive, controlled state
   initialize startup_mode();
   TickCount = 0:
   RunOnce = 0:
   // Debug only
#ifdef DEBUG
   //printf("Write this to the serial port...\r\n");
#endif // DEBUG
#ifdef DEBUG
   RecvLength = 6; // Length of received message...
   TSK DoCmdParse();
#endif // DEBUG
   while (1) {
      // This is the main execution loop that cycles forever.
      // 1. Check if it's time to create a new telemetry packet.
      TelemetryTick = TimeToXmitTelemetry();
```

```
if (TelemetryTick == 1) {
  PktCnt Cal++;
  if ((PktCnt_Cal >= PACKETS_PER_WEEK) && (CalMode)) {
   PktCnt Cal = 0;
   TSK DoCal();
   TickCount = 0;
  TSK_DoPacketFormat();
 // Start the ADC process
 if (ADC Start == 1) {
  ADC Start = 0;
  TSK_DoADC();
 }
 // 2. Check if there are characters to transmit.
 // If so, attempt to print one character (non-blocking)
 if ((XmitLength != 0)) {
  // In the process of sending a message
  if (!com putchar( *(pXmitPtr) )) {
   // A character was successfully placed into the buffer
   pXmitPtr++;
   XmitLength--;
  }
 } else {
  // Check for waiting telemetry or ACK packets.
  QueueWaitingMessage();
 }
 // 3. Process characters as they arrive (This is very fast!)
 TSK ProcessRxChars();
 // End of while(1) loop ...
}
```

#### Packet.c File Reference

#include "main.h"

#### **Functions**

- void TSK\_ProcessRxChars (void)
- void TSK DoCmdParse (void)
- void TSK\_DoAckPacket (void)
- void TSK\_DoNakPacket (tByte nak code)
- void TSK DoPacketFormat (void)
- char \* addChar (char ch, const char \*ptr)
- char \* addWord (tWord val, const char \*ptr)
- char \* addLong (tLong val, const char \*ptr)
- tByte **TimeToXmitTelemetry** (void)
- void QueueWaitingMessage (void)

#### **Variables**

- MCF type idata MCF
- tLong idata dos [3] INSTRUMENT CONTROL Dosimeter Telemetry Application (Main module) (Version 2.0: Flight Software)
- tLong idata dos zero [3]
- tLong idata cal\_pre [3]
- tLong idata cal post [3]
- tWord idata dos\_livetime [3]
- tWord idata ps 15V
- tWord idata ps\_5V
- tWord idata temps [3]
- tWord idata FrameCounter
- bit CalMode
- tLong idata TickCount
- tLong idata TotalTickCount
- bit TelemetryTick
- tByte idata XmitLength
- tByte idata DataBuff [48]
- tByte idata AckBuff [14]
- Status1 type idata Status1
- Status2 type idata Status2
- tByte idata \* pXmitPtr
- tByte idata \* pRecvPtr
- tByte idata RecvLength
- tByte idata **RecvBuff** [10]
- bit GSE
- bit Poll
- bit TxEnable

- bit INSTRUMENT CONTROL Enable
- bit ResetImminent
- bit Dos1TurnOn
- bit Dos2TurnOn
- bit Dos3TurnOn
- tLong idata RxTimer
- tWord idata PktCnt Cal
- MessageQueue msgQueue

```
Function Documentation
```

```
char* addChar (char ch, const char * ptr)
```

Definition at line 455 of file Packet.c.

char\* addLong (tLong val, const char \* ptr)

Definition at line 468 of file Packet.c.

char\* addWord (tWord val, const char \* ptr)

Definition at line 462 of file Packet.c.

void QueueWaitingMessage (void )

Definition at line 516 of file Packet.c.

tByte TimeToXmitTelemetry (void )

Definition at line 474 of file Packet.c.

void TSK\_DoAckPacket (void )

Definition at line 265 of file Packet.c.

void TSK\_DoCmdParse (void )

Definition at line 108 of file Packet.c.

void TSK\_DoNakPacket (tByte nak\_code)

Definition at line 283 of file Packet.c.

## void TSK\_DoPacketFormat (void )

Definition at line 303 of file Packet.c.

void TSK\_ProcessRxChars (void )

Definition at line 42 of file Packet.c.

#### **Variable Documentation**

tByte idata AckBuff[14]

Definition at line 65 of file MAIN.C.

tLong idata cal\_post[3]

Definition at line 36 of file MAIN.C.

tLong idata cal\_pre[3]

Definition at line 35 of file MAIN.C.

bit CalMode

Definition at line 54 of file MAIN.C.

tByte idata DataBuff[48]

Definition at line 64 of file MAIN.C.

tLong idata dos[3]

INSTRUMENT CONTROL Dosimeter Telemetry Application (Main module) (Version 2.0: Flight Software)

This code implements the full INSTRUMENT CONTROL dosimeter sensor, including all message formatting, data processing, and utility functions (ADC, CRC, ...)

Version Rev. 1.0 Created from the code written by Brian Zufelt for the development board and by code written by me for the EU model.

Chip type: Aeroflex UTMC UT69RH051 Program type: Firmware Core Clock frequency: 16.129000 MHz

Definition at line 33 of file MAIN.C.

bit Dos1TurnOn

Definition at line 85 of file MAIN.C.

bit Dos2TurnOn

Definition at line 86 of file MAIN.C.

bit Dos3TurnOn

Definition at line 87 of file MAIN.C.

tWord idata dos\_livetime[3]

Definition at line 37 of file MAIN.C.

tLong idata dos\_zero[3]

Definition at line 34 of file MAIN.C.

tWord idata FrameCounter

Definition at line 43 of file MAIN.C.

bit GSE

Definition at line 82 of file MAIN.C.

MCF\_type idata MCF

Definition at line 80 of file MAIN.C.

MessageQueue msgQueue

Definition at line 68 of file MAIN.C.

tWord idata PktCnt\_Cal

Definition at line 59 of file MAIN.C.

bit Poll

Definition at line 83 of file MAIN.C.

tByte idata\* pRecvPtr

Definition at line 75 of file MAIN.C.

tWord idata ps\_15V

Definition at line 38 of file MAIN.C.

tWord idata ps\_5V

Definition at line 39 of file MAIN.C.

tByte idata\* pXmitPtr

Definition at line 66 of file MAIN.C.

tByte idata RecvBuff[10]

Definition at line 73 of file MAIN.C.

tByte idata RecvLength

Definition at line 67 of file MAIN.C.

bit ResetImminent

Definition at line 48 of file MAIN.C.

bit INSTRUMENT CONTROL\_Enable

Definition at line 50 of file MAIN.C.

tLong idata RxTimer

Definition at line 60 of file MAIN.C.

Status1\_type idata Status1

Definition at line 78 of file MAIN.C.

Status2\_type idata Status2

Definition at line 79 of file MAIN.C.

bit TelemetryTick

Definition at line 46 of file MAIN.C.

tWord idata temps[3]

Definition at line 40 of file MAIN.C.

tLong idata TickCount

Definition at line 57 of file MAIN.C.

tLong idata TotalTickCount

Definition at line 58 of file MAIN.C.

bit TxEnable

Definition at line 49 of file MAIN.C.

tByte idata XmitLength

Definition at line 63 of file MAIN.C.

```
// Packet.c
// This file contains the code for assembling packets for transmittal to ARCS
#include "main.h"
extern MCF type idata MCF;
extern tLong idata dos[3];
extern tLong idata dos zero[3];
extern tLong idata cal pre[3];
extern tLong idata cal post[3];
extern tWord idata dos livetime[3];
extern tWord idata ps 15V;
extern tWord idata ps 5V;
extern tWord idata temps[3];
extern tWord idata FrameCounter:
extern bit CalMode;
extern tLong idata TickCount;
extern tLong idata TotalTickCount;
extern bit TelemetryTick;
extern tByte idata XmitLength;
extern tByte idata DataBuff[48];
extern tByte idata AckBuff[14];
extern Status1 type idata Status1;
extern Status2 type idata Status2;
extern tByte idata *pXmitPtr;
extern tBvte idata *pRecvPtr:
extern tByte idata RecvLength;
extern tByte idata RecvBuff[10];
extern bit GSE;
extern bit Poll;
extern bit TxEnable:
extern bit INSTRUMENT CONTROL Enable;
extern bit ResetImminent;
extern bit Dos1TurnOn:
extern bit Dos2TurnOn;
extern bit Dos3TurnOn;
extern tLong idata RxTimer;
extern tWord idata PktCnt Cal:
extern MessageQueue msgQueue;
// UART task functions
void TSK ProcessRxChars(void)
 // Create the state variable and initialize it to starting state
 static RxStateType state = WaitingFirstFEND;
 int rx char;
```

```
// if ((TickCount - RxTimer) > 1000)
// {
// Recover from a receive timeout - reset to idle state
// state = WaitingFirstFEND;
//
    RecvLength = 0;
//
    pRecvPtr = RecvBuff;
// RxTimer = 0xFFFFFFF;
// return;
// }
 // Check comm port for a character (-1 = empty)
 rx char = com getchar();
 if (rx char == -1) return;
 //com putchar(rx char);
 switch(state)
  case WaitingFirstFEND:
   if ( ((tByte)rx char) == FEND)
    state = WaitingFirstNonFEND;
    RecvLength = 0;
    RxTimer = TickCount;
   return;
   break;
  case WaitingFirstNonFEND:
   if ( (tByte)rx_char != FEND)
    state = ReadingChars;
     *(pRecvPtr) = (tByte )rx char;
    pRecvPtr++;
     RecvLength++;
   return;
   break;
  case ReadingChars:
   if ( (tByte)rx char == FEND)
    state = WaitingFirstFEND;
    RxTimer = 0xFFFFFFF;
    // Found the end of the command - now process it
```

```
CmdFound = 1;
    TSK DoCmdParse();
   } else {
    *(pRecvPtr) = (tByte )rx char;
    pRecvPtr++;
    RecvLength++;
   return;
   break;
  default:
   break;
void TSK DoCmdParse(void)
 tByte oldMode;
 tByte NAK code = 0x00;
 if (AnalysisMode == 0) {
  oldMode = 0;
 } else {
  oldMode = 1;
 // Ensure that the pointer is initialized to the receive buffer
 pRecvPtr = RecvBuff;
 // "Unescape" the string
 RecvLength = UNSLIP( pRecvPtr, RecvLength );
 // Check the CRC field
 pRecvPtr += (RecvLength - 2);
 if (crc16( RecvBuff, RecvLength-2 ) != *((tWord *)pRecvPtr)) {
  NAK_code = 0x03;
  goto bad exit;
 pRecvPtr = RecvBuff; // Return the pointer to the start of the message.
 // Check the destination address
 if (*(pRecvPtr)!= INSTRUMENT CONTROL ADDRESS) {
  NAK code = 0x04;
  goto bad exit;
```

```
// Check the source address
pRecvPtr++;
if (*(pRecvPtr)!= ARCS ADDRESS) {
 NAK code = 0x05;
 goto bad exit;
// Assertion: The command is from the avionics
        host and is intended for INSTRUMENT CONTROL
// Parse the message control field
pRecvPtr++;
Poll = ( *(pRecvPtr) & 0x80 ) >> 7;
B bit = (*(pRecvPtr) & 0x40) >> 6; // Pass through unaltered - we don't use this bit.
CmdCode = (*(pRecvPtr) & 0x1F);
Cmd = (*(pRecvPtr) & 0x0F);
if (Cmd == 0x01) { // "Instrument Reset" command (1 payload byte)
 if (RecvLength == 6) {
  INSTRUMENT CONTROL Enable = 1;
  pRecvPtr++;
  if ( *(pRecvPtr) != 0) { // Reset is imminent - perform an orderly shutdown
   ResetImminent = 1;
  } else {
   ResetImminent = 0;
  goto good exit;
 } else {
  NAK code = 0x02:
  goto bad exit;
} else if (Cmd == 0x02) { // "Configure" command (1 payload byte)
 if (RecvLength == 6) {
  INSTRUMENT CONTROL Enable = 1;
  CmdValid = 1:
  pRecvPtr++;
  GSE = (*(pRecvPtr) \& 0x80) >> 7;
  Status1.fields.SampleMode = (*(pRecvPtr) & 0x40) >> 6;
  if ((!CalMode) && ((( *(pRecvPtr) & 0x20) >> 5) == 1)) {
   // If CalMode goes from 0 --> 1, force a CAL
   PktCnt Cal = PACKETS PER WEEK;
   TickCount = 0xFFFF0000;
  CalMode = (*(pRecvPtr) \& 0x20) >> 5;
  TxEnable = (*(pRecvPtr) \& 0x10) >> 4;
```

```
// Test for dos1 pwr switching from off to on
  Dos1TurnOn = dos1 pwr;
  dos1 pwr = (*(pRecvPtr) & 0x08) >> 3;
  if ((dos1 pwr) && (!Dos1TurnOn))
   Dos1TurnOn = 1;
  else
   Dos1TurnOn = 0;
  // Test for dos2 pwr switching from off to on
  Dos2TurnOn = dos2 pwr;
  dos2 pwr = ( *(pRecvPtr) & 0x04) >> 2;
  if ((dos2 pwr) && (!Dos2TurnOn))
   Dos2TurnOn = 1;
  else
   Dos2TurnOn = 0;
  // Test for dos3 pwr switching from off to on
  Dos3TurnOn = dos3 pwr;
  dos3 pwr = (*(pRecvPtr) \& 0x02) >> 1;
  if ((dos3 pwr) && (!Dos3TurnOn))
   Dos3TurnOn = 1;
  else
   Dos3TurnOn = 0;
  AnalysisMode = ( *(pRecvPtr) & 0x01);
  // Test to see if the analysis mode has changed ...
  // If it has, need to change the system timer tick interval
  if ((oldMode == 0) && (AnalysisMode == 1))
   ChangeToAnalysisMode2();
  if ((oldMode == 1) && (AnalysisMode == 0))
   ChangeToAnalysisMode1();
  goto good exit;
 } else {
  NAK code = 0x02;
  goto bad_exit;
} else if (Cmd == 0x03) { // "Normal mode" command (0 payload bytes)
 if (RecvLength == 5) {
  // Initialize the normal mode of operation
  INSTRUMENT CONTROL Enable = 1;
  // Set the TurnOn flag for each dosimeter that was off
  if (!dos1 pwr) Dos1TurnOn = 1;
  if (!dos2 pwr) Dos2TurnOn = 1;
  if (!dos3 pwr) Dos3TurnOn = 1;
  initialize normal mode();
  // Change to faster timer tick
```

```
if (oldMode == 1)
    ChangeToAnalysisMode1();
   goto good exit;
  } else {
   NAK code = 0x02;
   goto bad exit;
 }
 else {
  NAK code = 0x01;
  goto bad exit;
 // Don't often use GOTOs, but sometimes they are useful
bad exit:
 CmdValid = 0;
 Ack = 0;
 if (Poll)
  TSK DoNakPacket( NAK code );
 goto exit func;
good exit:
 CmdValid = 1;
 Ack = 1;
 if (Poll)
  TSK DoAckPacket();
 Ack = 0;
exit func:
 pRecvPtr = (tByte *)RecvBuff;
 return;
}
// ACK/NAK packet formatting functions
void TSK DoAckPacket( void )
 // Start the data insertion point just past the MCF
 char *ptr = AckBuff + 3;
 tWord crc;
 // Pre-populate the values that are always the same
 AckBuff[0] = 0x11;
                      // Destination address (host(ARCS) = 0x11)
 AckBuff[1] = 0x56;
                      // Source address (INSTRUMENT CONTROL = 0x56)
 AckBuff[2] = MCF.value; // Message Control Field =
                 // 0xA0 for most NSP telemetry packets
 crc = crc16( (char *)(AckBuff), 3);
```

```
// Bytes 4,5
 ptr = addWord( crc, ptr);
 msgQueue.nAckLength = SLIP( AckBuff, ptr - AckBuff);
 return;
void TSK DoNakPacket( tByte nak code )
 // Start the data insertion point just past the MCF
 char *ptr = AckBuff + 4;
 tWord crc;
 // Pre-populate the values that are always the same
 AckBuff[0] = 0x11;
                      // Destination address (host(ARCS) = 0x11)
                     // Source address (INSTRUMENT CONTROL = 0x56)
 AckBuff[1] = 0x56;
 AckBuff[2] = MCF.value; // Message Control Field =
                // 0xA0 for most NSP telemetry packets
 AckBuff[3] = nak code;
 crc = crc16( (char *)(AckBuff), 4);
 ptr = addWord( crc, ptr);
                                  // Bytes 5,6
 msgQueue.nAckLength = SLIP( AckBuff, ptr - AckBuff);
 return;
// Telemetry/Calibration packet formatting function
void TSK DoPacketFormat( void )
 tLong temp;
 // Start the data insertion point just past the MCF
 char *ptr = DataBuff + 3;
 // There are six non-variable characters in the packet
 // They are: Status1, Status2, and the subcommutated
         VREF Frame data
 // NOTE: This is used for determining the length of the
       data/status string for CRC calculation
 tByte data length = 6;
 tWord crc:
 CmdCode = 0;
 // Pre-populate the values that are always the same
 DataBuff[0] = 0x11;
                      // Destination address (host(ARCS) = 0x11)
 DataBuff[1] = 0x56;
                       // Source address (INSTRUMENT CONTROL = 0x56)
 DataBuff[2] = MCF.value; // Message Control Field =
```

## // 0xA0 for most NSP telemetry packets

```
// Reset the "ACK" bit if set
Ack = 0;
// Insert the frame counter
ptr = addWord( FrameCounter, ptr );
// Insert the two status bytes
ptr = addChar( Status1.value, ptr );
ptr = addChar( Status2.value, ptr );
// Insert the (active) dosimeter channels
if (dos1 pwr) { // Dosimeter #1 active
 if (ContentID == CAL CONTENT)
  temp = cal post[0] - cal pre[0];
 else
  temp = dos[0] - dos_zero[0];
 if (temp > 0x80000000) temp = 0;
 ptr = addLong( temp, ptr );
 data length += 4;
if (dos2_pwr) { // Dosimeter #2 active
 if (ContentID == CAL CONTENT)
  temp = cal post[1] - cal pre[1];
 else
  temp = dos[1] - dos_zero[1];
 if (temp > 0x80000000) temp = 0:
 ptr = addLong( temp, ptr );
 data length += 4;
if (dos3 pwr) { // Dosimeter #3 active
 if (ContentID == CAL CONTENT)
  temp = cal post[2] - cal pre[2];
 else
  temp = dos[2] - dos zero[2];
 if (temp > 0x80000000) temp = 0;
 ptr = addLong( temp, ptr );
 data length += 4;
// Reset the flag that indicates that we are in the process of
// formatting the buffer string (this prevents ADC sampling during
// this period). NOTE: NEED TO CHECK WITH CHAD ON THIS.
// Note: This time should be very short, since most of the time
// spent in this whole routine is spent later in the CRC calcs.
```

```
TelemetryTick = 0;
if (ContentID == CAL CONTENT) {
 VrefFrame = 0:
// Insert the subcommutated power supply and temperature readings
if (VrefFrame == 0x00) {
                              // VREF Frame: 15V & 5V
 ptr = addWord( ps 15V, ptr );
 ptr = addWord( ps 5V, ptr );
} else if( VrefFrame == 0x01 ) { // VREF Frame: Temp1 & Temp2
 ptr = addWord( temps[0], ptr );
 ptr = addWord( temps[1], ptr );
} else if( VrefFrame == 0x02 ) { // VREF Frame: Temp3 & DOS1 run time
 ptr = addWord( temps[2], ptr );
 ptr = addWord( dos livetime[0], ptr );
} else {
 ptr = addWord( dos livetime[1], ptr ); // VREF Frame: DOS2/3 run time
 ptr = addWord( dos livetime[2], ptr ); // VREF Frame: DOS2/3 run time
// Insert the calculated CRC for the data packet
// Note: The fields included in this calculation are
II
      Status 1
//
      Status 2
II
      Dosimeter 1
                     0, 4
//
      Dosimeter 2
                     0, 4
//
      Dosimeter 3
                     0.4
      VREF Frame
II
II
//
      Total Length: {6, 10, 14, or 18}
II
crc = crc16( (char *)(DataBuff+5), data length);
ptr = addWord( crc, ptr);
// Insert the message CRC
// Note: The fields included in this calculation are
      Dest address 1
//
//
      Src Address
                     1
//
      Msg Ctrl Field 1
//
      Frame Counter 2
II
      Status 1
                   1
//
      Status 2
II
      Dosimeter 1
                     0, 4
//
      Dosimeter 2
                     0.4
//
      Dosimeter 3
                     0, 4
//
      VREF Frame
```

```
II
       Payload CRC 2
 II
 //
       Total Length: {13, 17, 21, or 25}
 II
 crc = crc16( (char *)(DataBuff), data_length + 7);
 ptr = addWord( crc, ptr);
 // Set UART send data pointer to the start of the message
 pXmitPtr = DataBuff;
 FrameCounter++;
 // Increment the frame counter and advance the VREF Frame (in Status2)
 // Only want to do hourly dump or CAL once then return to normal
 /* Hourly updates are not used at this point - we are sending total dose
   values each packet now...
 if (ContentID == HOUR CONTENT) ContentID = NORM CONTENT;
 if (ContentID == CAL_CONTENT)
  ContentID = NORM CONTENT;
  VrefFrame = 0;
 } else {
  VrefFrame++;
  //if (VrefFrame == 3) VrefFrame = 0;
 }
 // Reset CmdFound and CmdValid bits
 CmdFound = 0;
 CmdValid = 0;
 // 'Escape' any FEND or FESC characters in the data/validation packet
 // and, if transmit is enabled, return the result (the length of the
 // SLIP'ed data frame). If transmit is disabled, returning a 0 will not
 // cause any characters to be sent.
 if (TxEnable) {
  msgQueue.nDataLength = SLIP( DataBuff, ptr - DataBuff);
char *addChar( char ch, const char *ptr )
 char *p = ptr;
 *(p) = ch;
 return p+1;
```

```
char *addWord( tWord val, const char *ptr )
 // Need to add a word to the data, but safely (using addChar() method)
 return addChar( (char)(val >> 8), addChar( (char)(val & 0x00FF), ptr));
}
char *addLong( tLong val, const char *ptr )
 // Need to add a long (4 bytes) to the data, but safely (using addWord() method)
 return addWord( (tWord)(val >> 16), addWord( (tWord )(val & 0x0000FFFF), ptr));
}
tByte TimeToXmitTelemetry( void )
 // Math: With a tick timer of 2 ms, there are 500 interrupts
       per second. Therefore, we multiply the number of
 II
       seconds in the interval by 500 and convert it to hex.
 if (Status1.fields.SampleMode == 0) {
  // Low-speed (every 10 minutes)
  if (GSE == 1) {
   if (TickCount \geq (tLong )0x000009C4) { // 2,500 (5 secs)
     TickCount = 0;
     return 1;
   } else {
     return 0;
  } else {
   if (TickCount >= (tLong)0x000493E0) { // 300,000 (10 mins)}
     TickCount = 0;
     return 1;
   } else {
     return 0:
 } else {
  // High-speed (every 2 minutes)
  if (GSE == 1) {
   if (TickCount \geq (tLong )0x000000FA) { // 250 (0.5 secs)
     TickCount = 0;
     return 1;
   } else {
     return 0;
  } else {
   if (TickCount \geq (tLong )0x0000EA60) { // 60,000 (2 mins)
     TickCount = 0;
```

```
return 1;
   } else {
    return 0;
void QueueWaitingMessage(void)
 if (msgQueue.nDataLength != 0) {
  pXmitPtr = DataBuff;
  XmitLength = msgQueue.nDataLength;
  msqQueue.nDataLength = 0;
 } else if (msgQueue.nAckLength != 0) {
  pXmitPtr = AckBuff;
  XmitLength = msgQueue.nAckLength;
  msgQueue.nAckLength = 0;
}
#ifdef __DEBUG_
void FakeData( void )
 FrameCounter = 0x0000;
 Status1.value = 0x55;
 Status2.value = 0xE1;
 dos1_pwr = 1;
 dos2 pwr = 1;
 dos3 pwr = 1;
 dos[0] = 0x00000000;
 dos[1] = 0x00000000;
 dos[2] = 0x000000000;
 ps 15V = 0x7FC0;
 ps 5V = 0x7FDB;
 temps[0] = 3115;
 temps[1] = 3002;
 temps[2] = 2975;
#endif // __DEBUG__
```

#### **SIO.C File Reference**

#include "main.h"

#### Macros

- #define **TBUF\_SIZE** 16 /\*\*\* Must be one of these powers of 2 (2,4,8,16,32,64,128) \*\*\*/
- #define **RBUF\_SIZE** 16 /\*\*\* Must be one of these powers of 2 (2,4,8,16,32,64,128) \*\*\*/
- #define TBUF\_SPACE idata /\*\*\* Memory space where the transmit buffer resides \*\*\*/
- #define RBUF\_SPACE idata /\*\*\* Memory space where the receive buffer resides \*\*\*/
- #define CTRL\_SPACE data /\*\*\* Memory space for the buffer indexes \*\*\*/

#### **Macro Definition Documentation**

```
#define CTRL_SPACE data /*** Memory space for the buffer indexes ***/
```

Definition at line 26 of file SIO.C.

```
#define RBUF_SIZE 16 /*** Must be one of these powers of 2 (2,4,8,16,32,64,128) ***/
```

Definition at line 21 of file SIO.C.

```
#define RBUF_SPACE idata /*** Memory space where the receive buffer resides ***/
```

Definition at line 24 of file SIO.C.

```
#define TBUF_SIZE 16 /*** Must be one of these powers of 2 (2,4,8,16,32,64,128) ***/
```

Definition at line 20 of file SIO.C.

```
#define TBUF_SPACE idata /*** Memory space where the transmit buffer resides ***/
```

Definition at line 23 of file SIO.C.

```
SIO.C: Serial Communication Routines.
Copyright 1995-2002 KEIL Software, Inc.
#include "main.h"
Notes:
The length of the receive and transmit buffers must be a power of 2.
Each buffer has a next in and a next out index.
If next in = next out, the buffer is empty.
(next_in - next_out) % buffer_size = the number of characters in the buffer.
#define TBUF SIZE 16 /*** Must be one of these powers of 2
(2,4,8,16,32,64,128) ***/
#define RBUF_SIZE 16 /*** Must be one of these powers of 2
(2,4,8,16,32,64,128) ***/
#define TBUF SPACE idata
                            /*** Memory space where the transmit buffer resides
                            /*** Memory space where the receive buffer resides
#define RBUF SPACE idata
***/
#define CTRL SPACE data /*** Memory space for the buffer indexes ***/
#define INTERRUPT UART 4 /*** Interrupt level for Serial Port
/*_____
 */
#if TBUF SIZE < 2
#error TBUF SIZE is too small. It must be larger than 1.
#elif TBUF SIZE > 128
#error TBUF SIZE is too large. It must be smaller than 129.
#elif ((TBUF_SIZE & (TBUF_SIZE-1)) != 0)
#error TBUF_SIZE must be a power of 2.
#endif
#if RBUF SIZE < 2
#error RBUF_SIZE is too small. It must be larger than 1.
#elif RBUF SIZE > 128
```

```
#error RBUF_SIZE is too large. It must be smaller than 129.
#elif ((RBUF_SIZE & (RBUF_SIZE-1)) != 0)
#error RBUF SIZE must be a power of 2.
#endif
static TBUF SPACE unsigned char tbuf [TBUF SIZE];
static RBUF SPACE unsigned char rbuf [RBUF SIZE];
static CTRL SPACE unsigned chart in = 0;
static CTRL SPACE unsigned char t out = 0;
static CTRL SPACE unsigned char r in = 0;
static CTRL SPACE unsigned char r out = 0;
static bit ti restart = 0; /* NZ if TI=1 is required */
._____*/
static void com isr (void) interrupt INTERRUPT UART
Received data interrupt.
if (RI != 0)
 RI = 0;
 if (((r_in - r_out) & \sim (RBUF_SIZE-1)) == 0)
  rbuf [r_in & (RBUF_SIZE-1)] = SBUF;
  r in++;
Transmitted data interrupt.
if (TI != 0)
 TI = 0;
 if (t_in != t_out)
```

```
SBUF = tbuf [t_out & (TBUF_SIZE-1)];
  t out++;
  ti restart = 0;
 else
  ti restart = 1;
}
/*_____
  */
#pragma disable
void com initialize (void)
Setup TIMER1 to generate the proper baud rate.
*/
com baudrate (1200);
                                        // Was 1200
Clear com buffer indexes.
t in = 0;
t out = 0;
r in = 0;
r out = 0;
Setup serial port registers.
-----*/
SM0 = 0; SM1 = 1; /* serial port MODE 1 */
SM2 = 0;
REN = 1; /* enable serial receiver */
RI = 0; /* clear receiver interrupt */
TI = 0; /* clear transmit interrupt */
ti restart = 1;
ES = 1; /* enable serial interrupts */
PS = 0; /* set serial interrupts to low priority */
```

```
#pragma disable
void com baudrate (
 unsigned baudrate)
Clear transmit interrupt and buffer.
TI = 0; /* clear transmit interrupt */
t_in = 0; /* empty transmit buffer */
t_out = 0;
Set timer 1 up as a baud rate generator.
----*/
TR1 = 0; /* stop timer 1 */
ET1 = 0; /* disable timer 1 interrupt */
PCON |= 0x80; /* 0x80=SMOD: set serial baudrate doubler */
TMOD &= \sim 0xF0: /* clear timer 1 mode bits */
TMOD |= 0x20; /* put timer 1 into MODE 2 */
TH1 = (unsigned char) (256 - (16129000 / (16L * 12L * baudrate)));
TR1 = 1:
         /* start timer 1 */
/*_____
._____*/
#pragma disable
char com_putchar (
 unsigned char c)
If the buffer is full, return an error value.
----*/
if (com_tbuflen () >= TBUF_SIZE)
 return (-1);
Add the data to the transmit buffer. If the
transmit interrupt is disabled, then enable it.
```

```
tbuf [t_in & (TBUF_SIZE - 1)] = c;
t in++;
if (ti_restart)
 ti restart = 0;
       /* generate transmit interrupt */
 TI = 1;
return (0);
#pragma disable
int com_getchar (void)
if (com_rbuflen () == 0)
 return (-1);
return (rbuf [(r_out++) & (RBUF_SIZE - 1)]);
  */
#pragma disable
unsigned char com_rbuflen (void)
return (r_in - r_out);
/*_____
#pragma disable
unsigned char com_tbuflen (void)
return (t_in - t_out);
```

## List of Abbreviations, Symbols, and Acronyms

AFRL – Air Force Research Laboratory

COSMIAC – Configurable Space Microsystems Innovations and Applications Center

EEPROM – Electrically Erasable Programmable Read-Only Memory

LEO - Low Earth Orbit

MIT – Massachusetts Institute of Technology

NASA – National Aeronautics and Space Administration

RHAS - Radiation Hazard Assessment System

SPA – Space Plug-and-play Architecture

SDM – Satellite Data Module

SSM – Satellite System Module

UNM – University of New Mexico

UNP – University Nanosat Program

## DISTRIBUTION LIST

DTIC/OCP
8725 John J. Kingman Rd, Suite 0944
Ft Belvoir, VA 22060-6218 1 cy

AFRL/RVIL
Kirtland AFB, NM 87117-5776 2 cys

Official Record Copy
AFRL/RVSE/Keith Avery 1 cy